A SNAPSHOT OF SINGLE PHOTON APPLICATIONS

Dr David Armstrong

david.armstrong@fraunhofer.co.uk



Fraunhofer CAP's current status and positioning


- Fraunhofer UK/CAP founded in 2012 as an IRTO partnered with University of Strathclyde and Fraunhofer IAF
- 'Laser and Laser Systems' Business Unit
 'Quantum Technology' Business Unit
 - Scientific lasers for sensing, imaging, metrology, comms...
- **106 funded company partners** from SMEs to multi-nationals
- Prominent position in Quantum Technology, LIDAR and stand-off chemical and environmental sensing







Quantum technology themes




Dr David Armstrong, Fraunhofer UK, Epic, Single Photon Sources and Detectors at LWP

Fraunhofer


Positioning in QT

- Fh-CAP supports a wide range of industry partners
 - Introducing new industry into IUK programme
- Fh-CAP participates in 30% of the IUK QT programme
- Fh-CAP secured a 6% share of the IUK QT funding
- Diversifying portfolio of funding sources






Single photon detection for time-gated Raman Spectroscopy




System overview





'Looking through' high concentration clouds







Entangled photon sources through (SPDC)

Nonlinear crystal





- We can use entangled photons for secure communication. We will know for certain whether anyone has been eavesdropping
- We can securely communicate information (QKD)
 - Protect critical infrastructure
 - Secure our data from decryption
- Sources also have applications in quantum imaging, sensing and lidar.









Integrated sources of quantum light

- At Fraunhofer CAP we have a number of programmes of work exploring the use of waveguide-based devices.
- The geometry enables extension of interactions length whilst maintaining high pump intensity.
- Efficient generation into single transverse mode. The collection efficiency is decoupled from the optimal focusing position.
- Possibility for further integration with fibres and lasers for compact sources. We have developed a process with optimised mode-matching to single-mode fibre.
- For high rates of secure key:
 - High pair generation rate is required.
 - low-probability of multi-photon events (e.g. mean photon number < 0.1)






Waveguides in PPLN fabricated by ultrafast laser inscription




- Using ultrafast laser inscription (ULI) we can write low-loss waveguide buried in transparent materials
- We have fabricated waveguides in PPLN that are single-mode at 780 nm and 1560 nm.
- We have confirmed the nonlinear efficiency and phase matching conditions through second-harmonic generation



Spontaneous parametric downconversion tests

- Pumping the waveguides with 780 nm light we have demonstrated spontaneous parametric down-converion to 1560 nm
- Using superconducting nanowire detectors we have been able to characterise coincidence to accidental ratios and heralding efficiencies.



Dr David Armstrong, Fraunhofer UK, Epic, Single Photon Sources and Detectors at LWP

Fibre

coupling

HWP PBS HWP

Collimator

PM fibre @ 780 nm

A SNAPSHOT OF SINGLE PHOTON APPLICATIONS

Dr David Armstrong

david.armstrong@fraunhofer.co.uk



